## Minimum System Requirements for Scribe EC With Opti Ec

#### Print Station & 1-Drive Models – Minimum System Requirements:

- Minimum Pentium® III or compatible personal computer @ 800 MHz or faster
- Windows 2000 Professional (Service Pack 4 or higher) or Windows XP Pro Service Pack 1.0a or higher
- 512 MB RAM

DIGITAL

- 7200 RPM ATA-100 hard drive with 850 MB for CD-R or 5GB (NTFS) for DVD-R of free hard disk space fully defragmented
- Monitor: 800 x 600 display, 16-bit color recommended
- Two button mouse
- High quality recordable CD-Rs / DVD-Rs
- One free PCI slot for 1 Drive System, Not required for Print Station Only.
- One <u>external</u> COM Port (COM1 or COM2) \**Two <u>external</u> COM ports are needed if using MF DIGITAL Spectrum2 or Prism Plus (COM1 <u>and</u> COM2).*
- WinASPI driver layer (Included)
- IEEE-1394 B Adapter (Included)
- Appropriate IEEE-1284 printer cable if attached
- \* A USB to Serial Converter can be used if no COM port is available.

#### 2-Drive & 4-Drive Models – Minimum System Requirements:

- Minimum Pentium® 4 or compatible personal computer @ 2 GHz or faster
- Windows 2000 Professional (Service Pack 4 or higher) or Windows XP Pro Service Pack 1.0a or higher
- 1 GB RAM (Asynchronous Operation)
- 7200 RPM ATA-100 hard drive with 850 MB for CD-R or 5GB (NTFS) for DVD-R of free hard disk space fully defragmented
- Monitor: 800 x 600 display, 16-bit color recommended
- Two button mouse
- High quality recordable CD-Rs / DVD-Rs
- One free PCI slots
- One external COM Port (COM1 or COM2) \**Two<u>external</u> COM ports are needed if using MF DIGITAL Spectrum2 or Prism Plus (COM1 <u>and</u> COM2).*

# IF YOU PURCHASED A PRINT STATION – SKIP THIS PAGE

## Installing the Firewire Adapter Card

*Note:* You should never attempt to service a unit without ensuring proper anti-static protection. The use of a grounding strap, or other such grounding device, is advised. In addition, the internal configuration of your computer may be different from the computer pictured below.

(fig. 1)

One and two drive ScribeECs require one IEEE-1394 card. Four drive systems require two IEEE-1394 cards.

- 1. Shut down the PC.
- 2. Turn the PC's power off.
- 3. Unplug the PC.
- 4. Remove the PC's cover as indicated in the PC's manual.
- 5. Locate an empty PCI slot, as seen in (fig.1).
- 6. Install the firewire adapter card (fig. 2).

#### Installing the Drive Bay

1. Place the drive bay onto the base unit as seen in (fig. 1).





2. Position the drive bay so that the front right corner sits over the dotted line (fig. 2). Proper position is shown in (fig. 3).













### Making the Connection

#### 1 & 2 Drive Systems



**4 Drive System** 

Two drive unit uses one fire wire adapter card and one cable.

Four drive unit uses two firewire adapter cards and two cables... Install one cable in each firewire card.

## Installing the SCRIBE EC Software

- 1. Insert the SCRIBE EC software CD.
- 2. From the CD ROM drive of the computer, click *Install SCRIBE Software*.
- 3. Click Next (fig. 1).
- 4. Accept the license agreement and click *Next* (fig. 2).







5. Click Install (fig. 3).



6. Click *Finish* (fig. 4).

#### Installing the SCRIBE EC Alignment Utility for Aligning the Drive Tower

😓 Scribe EC System Aligner Setup

OK

Click this button to install Scribe EC System

4

Scribe LC System Aligner Setup

Directory

in the installation by clicking the britten hel

Welcome to the Scribe EC System Aligner installation program.

E<u>x</u>it Setup

Aligner software to the specified

Setup cannot install system files or update shared files if they are in use. Before proceeding, we recommend that you close any applications you may be running.

- 1. Insert the SCRIBE CD into the CD-ROM drive of your PC.
- 2. Click on setup.exe of the alignment utility and Click *OK* (fig. 1).
- 3. Click the button indicated in (fig. 2).

- 4. Enter a name for the group where the Alignment Utility will be located. Click *Continue* (fig. 3). The Scribe Program Utility will appear under *Start / Programs / "group name"* after installation is complete.
- 5. A progress bar will appear (fig. 4).
- C:\Program Files\Scribe EC Printer Aligner\ Change Directory (fig. 2) Egit Setup 🖫 Scribe EC System Aligner - Choose Program Gr × Setup will add items to the group shown in the Program Group bo You can enter a new group name or select one from the Existing Groups list. Program Group: MEONINA Existing Groups: MFOptical (fig. 3) <u>⊆</u>ontinue Cancel 🚭 Scribe EC System Aligner Setup × Destination File: C:\WINDOWS\System32\MSCOMM32.OCX 26% (fig. 4) Cancel

×

x

(fig. 1)

6. Click *OK* (fig. 5) to finish installation.



### Installing the OptiEC Printer Driver

- 1. Click Start-> Settings-> Printers
- 2. Click Add New Printer
- 3. The "Welcome to the Add Printer Wizard" window will appear (fig 1). Click Next.
- 4. In the "Local or Network Printer" window, uncheck the "Automatically detect installed printer" option, leaving the "Local printer attached to computer" option (**fig 2**) and click Next..
- 5. In the "Select a Printer Port" window, leave the default as LPT1 (fig 3) and click Next.
- In the "Install Printer Software" window, click the "Have Disk" button (fig 4). You will then be prompted to "Install from Disk", click the "Browse" button (fig 5). Select the location of the printer driver from your CD-ROM drive in the PC (fig 6).







#### Installing the MF Digital OptiEC Printer Driver (cont.)

Add Printer Wizard

MF DIGITAL Opti EC

Add Printer Wizard

ME DIGITAL Onti EC

A This driver is not digitally signed! Tell me why driver signing is important

stall Printer Software The manufacturer and model determine which printer software to use

Use Existing Driver A driver is already installed for this printer. You can use or replace the existing driver.

Do you want to keep the existing driver or use the new one? <u>Keep existing driver (recommended)</u> <del>Replace existing driver</del>

Select the manufacturer and model of your printer. If your printer came with an installation disk, click Have Disk. If your printer is not listed, consult your printer documentation for

fig 7

fig 8

Windows Update Have Disk.

<Back Next> Cancel

<Back Next> Cancel

7. After specifying the driver for the MF Digital OptiEC printer, the printer "MF Digital OptiEC" will appear in the "Add Printer Window" (**fig** 7). Click Next to continue.

8. In the "Name your Printer" window, leave the printer as the default name, and select the printer to be the default printer (**fig 8**) and click Next.

9. In the "Printer Sharing" window, select "Do Not Share the Printer" (**fig 9**) and click Next.

10. Say No to "Print Test Page" (fig 10) and click next.

11. The "Completing the Add Printer Wizard" window will appear (**fig 11**). Click Finish. After clicking finish, the MF Digital OptiEC printer driver will be installed. You will be asked to accept that the printer driver is not digitally signed by Microsoft, click Continue (**fig 12**). You have now successfully installed the printer.



# Adjusting the MF Digital OptiEC Printer Driver Settings

#### **Printer Spooling**

It is important to disable printer spooling on the MF Digital OptiEC printer. To do so, please follow the steps below:

- 1. Go to Start-> Settings -> Printers
- 2. Right-click on the MF Digital OptiEC printer in the Printers Folder
- 3. Go to Properties
- 4. Go to the Advanced Tab
- 5. For the Scribe Program to use the printer effectively, please match the settings of your printer driver to the example on the right-side of this page.
- 6. To save settings, Click Apply and OK to exit.

\*\*\*NOTE: Any changes made to the printer driver settings, require a NEW PRN file to be made. If you change one of the settings, be sure to create a NEW PRN file.\*\*\*

-		Properties		
General	Sharing Ports	Advanced	Color Manag	ement About
⊙ A <u>l</u> wa	ays available			
⊖ Ava	la <u>b</u> le from	12:00 AM	Ç To	12:00 AM 🔶
Priority:	1			
Dri <u>v</u> er:	MF DIGITAL Op	oti EC		Ne <u>w</u> Driver
⊙ 9 ⊚ 9 ⊙ Print	itart printing after l itart printing immed directly to the prin	ast page is sp diately Iter	ooled	raster
● 9 ● 9 ● Print	itart printing after l itart printing immed <b>directly to the prin</b> I mismatched docu	ast page is sp diately Itel	ooled	
● 9 ● 9 ● Print ● Hold ● Print	itart printing after I itart printing immer directly to the prin I mismatched docu spooled documer	ast page is sp diately ited uments its first	ooled	
<ul> <li>S</li> <li>S</li> <li>Print</li> <li>Hold</li> <li>Print</li> <li>Kee</li> </ul>	itart printing after I itart printing immed directly to the print mismatched docu spooled documer printed documer	ast page is sp diately t <b>ter</b> uments nts first its	ooled	
● S ● S ● Print ● Hole ● Print ● Kee ♥ Ena	itart printing after I itart printing immer directly to the print I mismatched docu spooled documer p printed documer ble advanced print	ast page is sp diately ited uments its first its fing features	ooled	
● S ● Print ● Holo ● Print ● Kee ● Ena	itart printing after I itart printing immer directly to the print I mismatched docu spooled documer printed documer ble advanced print ing Defaults	ast page is sp diately inter uments ints first its Fring features Pring Proce	essor	Separat <u>o</u> r Page

#### Aligning the Drive Tower

- 1. From your Start Menu Open the *SCRIBE EC Alignment Utility* (fig. 1). It will be located in the folder designated when you installed the alignment utility. Choose the appropriate COM Port which the Scribe EC Loader is installed on. Select all other printers and drives, and Click Start *Test*.
- 2. Follow the instructions by opening the top CD/DVD drive tray, and Clicking *Yes* (fig. 2). The picker arm will hover a disc over the drive tray, observe the discs position and make the adjustments to the drive tower (fig. 3).
- 3. Click *Yes* when you are satisfied with your adjustment (fig. 4).
- 4. The picker arm will then place the disc onto the drive tray. Follow the on screen instructions and click *OK* (fig. 5).
- 5. Once you are satisfied with the drive tower alignment, tighten the thumb-screws located on **both** sides of the drive tower (**fig. 6**).







## Aligning the MF Digital OptiEC Printer

Before starting the Alignment Utility, position the front end of the printer plate on the dotted line of the drive tower.

- 1. From your Start Menu Open the SCRIBE EC Software.
- 2. Once the *Scribe EC Software* opens, click on the Settings tab.
- 3. Click *Change Settings* and select the MF Digital OptiEC Printer. After making this selection, you will need to restart the *Scribe EC Software* program.
- After restarting the Scribe EC Software program, go to the Settings Tab. You will now see a button that says "Test Loading and Unloading the Printer". Click this button. (fig 1)
- 5. A Printer Alignment Box will appear. First, you will click the "Pick up a disc from the Input spindle and put it down on the printer tray" (fig 2). Adjust the printer so that the CD is aligned in the printer tray (fig 3).
- 6. After ensuring proper placement of the CD on the printer, continue with the Alignment Utility and pick up the CD from the printer tray.
- 7. After you are satisfied with the alignment of the CD on the printer tray, lock the printer in place by tightening the thumb screws on the printer plate to hold the printer in place.





(fig. 3)

Alert: